



# **BULLDOG SECURITY**

Burglar & Fire Alarms  
Sales Service Monitoring

## **HOW TO TEST YOUR SECURITY SYSTEM COMMUNICATIONS**

**BEFORE YOU START YOU MUST KNOW YOUR ACCOUNT NUMBER, PASSCODE AND CENTRAL STATION PHONE NUMBER. YOU WILL FIND THIS INFORMATION ON THE CUSTOMER ID CARDS. IF YOU DO NOT KNOW, CONTACT OUR OFFICE.**

1. CALL CENTRAL STATION.
2. PLACE YOUR SYSTEM ON TEST USING YOUR ACCOUNT NUMBER & PASSCODE INFORMATION FOR 1 HOUR.
3. ARM YOUR SYSTEM. WAIT 60 SECONDS
4. ALLOW SYSTEM TO REMAIN IN ALARM FOR 90 SECONDS. DISARM YOUR SYSTEM
5. CALL CENTRAL STATION.
6. TELL THEM YOU ACCOUNT NUMBER AND PASSCODE. ASK IF THEY RECEIVED A SIGNAL FROM YOUR ACCOUNT.
7. IF NO SIGNAL REPEAT #2 AND 3.
8. IF NO SIGNAL CALL BULLDOG SECURITY FOR SERVICE CALL.
9. IF YOU HAVE A PHONE SERVICEMAN WORKING ON YOUR PHONE LINES, TEST YOUR SYSTEM BEFORE ALLOWING THEN TO LEAVE OR SIGNING ANYTHING.
10. PLEASE SEE YOUR OWNERS MANUAL FOR TESTING RECOMMENDATIONS. THE ALARM EQUIPMENT MANUFACTURER RECOMMENDS A WEEKLY TEST OF YOUR ALARM EQUIPMENT!

1480 Old Deerfield Road, Suite 22  
Highland Park, IL 60035  
Phone: 847-432-9900 Fax: 847-432-9980